


SELECTOR SWITCH

POSITION	L1-1	L1-4	N-2	N-3
OFF	0	0	0	0
COOK	X	0	X	0
COOL DOWN	0	X	0	X

ELECTRIC COOK TIMER

POSITION	1-2	1-4
OFF	0	0
TIMING	X	0
Buzzer Sounds Timing Cycle Ends	0	X

LEGEND
 0-OPEN
 X-CLOSED



>>
 INDICATES QUICK
 DISCONNECT
 TERMINAL

- COLOR CODE**
- BK-BLACK
 - RD-RED
 - W-WHITE
 - BL-BLUE
 - Y-YELLOW
 - GY-GREY
 - V-VIOLET
 - OR-ORANGE
 - GR-GREEN

BLODGETT

**DFG-100/200 W/COOK
 115 VAC 60 HZ
 SINGLE PHASE
 W/SOLID STATE T' STAT
 2 SPEED**