



## *New Product Programming for "Orange Label" Grilled Chicken*

1. To enter programming mode, press and hold the "P" button for 3 seconds
2. Press ▼ arrow down button to **Programming** and press "P".
3. Enter programming access code **1724** and press "P".
4. **Recipe** will be displayed and press "P".
5. Select a Product Key 1-16 to be changed.
6. Press ▼ arrow down button to **Time** and press "P".
7. Enter the cook time based on the chart below for that recipe button and press "P" twice.
8. Press ▼ arrow down button to **Temperature** and press "P".
9. Enter the temperature based on the chart below for that recipe button and press "P".
10. Press ▼ arrow down button to **Fan Reverse Time** and press "P".
11. Enter the fan reverse time based on the chart below for that recipe button and press "P".
12. Press ▼ arrow down button to **EXIT** and press "P".
13. Select the next product key to be programmed and follow steps 5-12 again.
14. To exit programming, press ▼ arrow down button to **EXIT** and press "P".

Product Key #	Menu Name	Stage 1 Cook Time	Cook Temperature	Fan Reverse Time
1	KGC 1Head	20:30	425°	8:00
2	KGC 1Head	20:30	425°	8:00
3	KGC 1Head	20:30	425°	8:00
4	KGC 1Head	20:30	425°	8:00
5	KGC 1Head	20:30	425°	8:00
6	KGC 12Pc Dark	19:00	425°	8:00
7	KGC 12Pc Dark	19:00	425°	8:00
8-15	Not used			
16	Season Grill Racks	10:00	425°	8:00